

SWIPE CRYSTAL

OXYGENATED CLEANING POWDER FOR DISHWASHERS AND OTHER APPLICATIONS

BENEFITS

POWERFULLY ACTIVE	The oxygenated process makes this an extremely effective detergent for the Dishwasher to remove grease, food residue and tannin, as well as numerous other cleaning applications.
SAFE	Gentle on fragile crockery. Because it does not contain Chlorine it will not pale designs, etch or bleach porcelain or glassware. It is suitable for all makes of Dishwashers.
ECONOMY FACTOR	Based on 1kg will give approximately 66 loads. A highly competitive product which uses half the quantity of most other products.

HOW TO USE

Use coarse salt and final rinse-aid according to dishwasher manufacturer's instructions.

For a normal wash, dispense 15 grams of SWIPE CRYSTAL into the machine.

OTHER USES

- Showers – Scrub floor and tiles
- Stains of fabrics – Spray SWIPE for grease stains and SWIPE BRITE for fruit, wine or curry stains. Rinse and soak in cold water to which 1-2 level measures of SWIPE CRYSTAL has been added, leave overnight.
- Use instead of bleach to soak tea towels or any discoloured items. It will boost the cleaning process.
- For tannin stains on teacups and teapots, mix with a little water to make a paste and rub on.
- Burnt or greasy pots or roasting pans – Add ½ measure and bring to the boil.

TO DEMONSTRATE

- Add 5 ml to a tannin stained teapot. Fill with water. Agitate with a brush. Leave for ½ hour.
- Add a small quantity of SWIPE CRYSTAL to a glass of water, and stir. It dissolves completely, while the oxygen activator enlivens the crystal clear mixture.

MAIN ACTIVE INGREDIENTS

BIODEGRADABLE

A CONCENTRATED ALKALINE DETERGENT

OXYGEN ACTIVATOR

CONTAINS NO CHLORINE

WARNING - DO NOT ADD CHLORINE TO SWIPE CRYSTAL